



Models: BTC-5PX and BTC-6PX

IMPORTANT: During the software installation, your camera cannot be powered off via the power switch, or lose battery supply voltage via weak batteries, or by ejecting the battery tray. If any of these events occur, your camera may no longer be functional. Your camera will need to be returned to our warranty center to have the software reloaded onto our production line equipment. Before you begin your new software installation, please insert **new** alkaline AA batteries in your camera. Please follow the instructions below to upgrade the software on your Browning PX1080 trail camera. If you have any questions or need assistance with upgrading your camera software, you can contact us at 1-888-618-4496, Option 2.

This software upgrade is designed to correct an issue when viewing videos on a SD card 64GB or larger in size via a Windows PC.

- Download the appropriate file for your model trail camera to your computer. Do not open the file as your computer will not be able to read the file. (BTC5PX.bin for model BTC-5PX and BTC6PX.bin for model BTC-6PX).
- Save the file to a blank SD card.
- With the camera powered Off install the SD card that has been sent to you preloaded with the software update.
- Power the camera on and wait for it to stop at the Home Screen.
- Before the camera takes a picture press the Mode Button to enter the camera's Setup Menu.
- Press the Up Arrow Button once to get to 'SW Upgrade.'
- Press the E Button and 'No' will begin flashing.
- Use the Up Arrow Button to change 'No' to 'Yes' and Press E.
- The camera's display screen will read 'Upgrading' for approximately 30 to 60 seconds.
- When the update is complete the camera will power itself off and back on.
- Now the camera is ready to be used. You can use the 'Delete All' function on the camera to clear the SD card.