



**Model: BTC-4E40**

**IMPORTANT:**

During the software installation, **do not** power off your camera using the power switch, remove the battery tray, or allow the batteries to lose voltage (e.g., due to weak batteries). If any of these events occur, your camera may become non-functional and will need to be returned to our warranty center for software reinstallation using our production line equipment.

Before beginning the installation, please insert **new alkaline AA batteries** into your camera to ensure stable power throughout the process.

Follow the instructions below to upgrade the software on your **Browning Command Ops Elite 40** trail camera.

This software update addresses an issue reported by some users where, in **Video Mode**, the camera continues recording beyond the set video length—both during the day and at night.

If you have any questions or need assistance, please contact us at **1-888-618-4496, Option 2**.

- Download and save the file named BTC4E4025.bin to your computer's desktop.  
*Note: The file is not meant to be opened as your computer will not recognize it.*
- Insert a clean (empty) SD card into the computer and save the file to the SD card.
- With the camera powered Off insert the SD card into the camera.
- Power the camera on and wait for it to stop at the Home Screen.
- Before the camera takes a picture press the Mode Button (M) to enter the camera's Setup Menu.
- Press the Up Arrow Button once to get to 'SW Upgrade.'
- Press the OK Button.
- Use the Right Arrow button to select 'Y' and press the OK button.
- The camera's display screen will read 'SW Upgrading' for approximately 30 to 60 seconds.
- When the update is complete the camera display will say 'Done' and cycle the power itself.
- The camera's software has now been updated.
- Now the camera is ready to be used. You can use the 'Delete All' function on the camera to clear the SD card.